Model 1...

Turn the thermostat knob clockwise to its maximum.

Turn the thermostat knob anti-clockwise to its maximum.

Whichever Model You Are Using...

The compressor is fitted with a timed delay switch and will not run until 4 minutes have passed.

Once running, allow a minimum of 10 minutes for it to begin cooling.

Once the desired room temperature has been reached gradually turn the thermostat knob anticlockwise (model 1) or clockwise (model 2) until the machine clicks. The unit will now only emit chilled air when the room temperature rises.

Finally **adjust the fins** at the front of the machine **to direct the airflow as required.**

EQUIPMENT CARE

Never push the equipment beyond its design limits. If it will not do what you want with reasonable ease and speed, assume you have the wrong size or quantity of air conditioners for the job. Contact your local HSS Hire Shop for advice.

Keep the equipment clean - you will find this less of a chore if you clean it regularly, rather than wait until the end of the hire period.

Only use the air conditioner for the purpose it was designed for. Improper use may cause expensive damage and could be dangerous.

Regularly check the water drain tank (every 3-4 hours). There is **a red warning lamp** on the control panel, which **will illuminate when** the tank is **full**. The unit will also turn itself off.

Set all switches to OFF and leave the unit to stand for a minimum of 5 minutes before emptying the tank.

Never remove the tank when the unit is operating and always ensure that the tank is replaced correctly before restarting.

To empty (Model 1 only, release the catch on the compartment cover) **slide the tank out, empty then replace.**

When not in use, store the equipment somewhere clean, dry and safe from thieves. Protect this equipment from frost and freezing conditions.

FINISHING OFF

Switch the unit OFF and unplug from its power supply, then empty the water tank.

Remove the exhaust hose, coil the power supply cable and give the unit a final clean up ready for return, to your local HSS Hire Shop.



...any comments?

If you have any suggestions to enable us to improve the information within this guide please fax your comments or write to the Product Manager at the address below

Fax: 020 8687 5001

©HSS Hire Service Group Plc 2003 No. 809/02

Group Office: 25 Willow Lane, Mitcham, Surrey CR4 4TS

Web Site: http://www.hss.com

Operating & Safety Guide 809

HSS Hire Shops



Large Air Conditioner

A heavy duty air conditioner for use in large offices, conference rooms, restaurants and similar environments.



Code 56764

GENERAL SAFETY

For advice on the safety and suitability of this equipment **contact your local HSS Hire Shop.**

There is a serious risk of personal injury if you do not follow all instructions laid down in this guide.

The hirer has a responsibility to **ensure that all necessary risk assessments have been completed** prior to the use of this equipment.

This equipment should only be used by an operator who has been deemed competent to do so by his/her employer.

This equipment should be used by an able bodied, competent adult who has read and understood these instructions. Anyone with either a temporary or permanent disability, should seek expert advice before using it.

Keep children, animals and bystanders away from the work area. Cordon off a NO GO area using either cones, barriers or tape, available for hire from your local HSS Hire Shop.

Never use this equipment if you are ill, feeling tired, or under the influence of alcohol or drugs.

This equipment is heavy (80kg), never attempt to lift it, always get help.

Always transport and store the unit in an upright position, never lay it on its side.

Never move this equipment by its power supply cable.

Always switch OFF and unplug the equipment when not in use.

Ensure the work area is well lit and ventilated, if in doubt, ask about lighting and ventilation equipment at your local HSS Hire Shop.

Never leave the unit running and unattended.

When positioning the unit, consider the floor surface. Avoid placing the unit directly on to carpet or any other surface that maybe easily damaged.

Check the condition of the equipment before use. If it shows signs of damage or excessive wear, return it to your local HSS Hire Shop.

ELECTRICAL SAFETY

The HSS Large Air Conditioner plugs into a standard 230V 13amp power socket.

If the equipment fails, or if its power supply cable or plug becomes damaged, return it. Never try to repair it yourself.

Keep cables out of harm's way, and clear of the work area.

Extension leads should be fully unwound and loosely coiled, away from the equipment. Never run them through water, over sharp edges or where they could trip someone.

Keep the equipment dry, using electrical equipment in very damp or wet conditions can be dangerous.

To reduce the risk of electric shock, always use a suitable RCD (Residual Current-Operated Device) available from your local HSS Hire Shop. Or power the equipment from a mains circuit with a built in RCD.

Ensure the machine and power socket are switched OFF before plugging into the power supply.

GETTING STARTED

Never operate the unit in very hot or cold conditions, it works properly only at temperatures between 21°C and 35°C. Performance will also suffer in very humid conditions.


If the room temperature is above 35°C, open all doors and windows and operate the units fan only until the temperature has reduced.

When setting up or restarting, allow the unit to stand / settle for 15 minutes before switching ON.

Set the unit up on a firm, level surface where the air from the machine can circulate freely and where the motor noise will not be a nuisance.

Do not site the unit close to any surface sensitive to heat, cold or moisture.

Fit the 2.5 metre discharge hose into the back of the unit, then extend it to the chosen discharge point.



Attaching The

Discharge Hose

The hose is long enough to be able to discharge into ceilings, windows and doors using the fishtail fitting provided.

Ensure the water drain tank is correctly fitted then plug the unit into its power supply and switch the supply ON.

With the amber power supply light on, **press the**

red 'Fans On' switch or 'Fan ON/OFF Button' to start the fan.

Use the fan speed selector switch or fan speed knob to select the desired fan speed.

If chilled air is required, press the green 'cooling on' button, then depending on which model you have...

